

# 9304-HUV-M88A84K -Hunter HDMI 2.0 4K Matrix 8x8 With Audio

# User Manual







## Product Introduction

Hunter HDMI matrix switcher supports 4K@60 with 8 HDMI 2.0 inputs and 8 HDMI 2.0 outputs; each HDMI port has audio 3.5 port, the resolution can up to 4K60Hz and all ports are HDCP 2.2 compliant. User Control methods - IR remote control, 2-Press push buttons with background blue light, WEB GUI, APP and RS232/UDP commands, this matrix switcher can work with the Blu-Ray Players, Set-Top boxes, Home Theater, and game consoles etc HDMI input sources to route to the HDMI displays, it has been widely used in different audio visual applications.

#### Features



- 8 HDMI2.0 inputs with 3.5mm audio embedded for each input
- 8 HDMI2.0 outputs with 3.5mm audio de-embedded for each output
- Supports HDMI2.0, HDCP2.2
- The resolution can up to 4K@60Hz
- Supports LPCM 7.1CH, Dolby TrueHD, Dolby Digital and DTS-HD Master Audio
- Supports IR remote control(IR remote control codes are available)
- Supports smart EDID management, including 8-output EDID, 15 internal EDID.
- Supports RS-232 and TCP/IP Control(WEB GUI, APP and IR remote)
- Supports 2-press push buttons control with blue lights
- Supports to rename the inputs and outputs, scenes

# Connection Diagram





#### Specification

84 S.

Resolutions	480i, 576i, 480p, 576p, 720p, 1080i, 1080p@24/30/50/60Hz, 4K@60Hz
Input ports	8* HDMI, 1* RS-232(control), 1 * RJ-45(control), 8*3.5mm audio
Output Ports	8* HDMI, 1* RS-232(control),8*3.5mm audio
ESD Protection	±8kV (Air-gap discharge), ±4kV (Air-gap discharge)
Controlling	IR remote control, front buttons control, RS232, UDP
Power	DC:12V 2A
Dimension	440*260*44(mm)
Weight	4Kg

Panel description

**Front Panel** 



- **LCD screen**: for the switching, EDID, IP etc information display.
- **OUTPUT**: 8 HDMI input buttons
- INPUT: 8 HDMI output buttons
- CONTROL:
- **UP:** for upward controlling, or when press input and press UP to all outputs
- **EDID**: Press it to enter EDID set mode.
- **SAVE:** Press to save the switching status.
- **Down**:for upward controlling
- ENTER: Press to confirm to save the setting.
- **RECALL:** Press it to recall the presets/scenes.
- IR: IR receiver for the IR remote control



- 1. For the ground wiring
- 2.3.5mm audio input for each HDMI input
- 3. INPUT: 8 female HDMI Input ports
- 4. OUTPUT: 8 female HDMI output ports
- 5.3.5mm audio outputs for each HDMI output
- 6. Control other devices: from the WEB GUI setup to fill out the commands
- 7. RS232 IN&RS232 OUT: RS232 ports for the RS232 control
- 8. LAN: for the IP/TCP control, the default IP address is 192.168.1.80
- 9. DC12V: power supply port
- 10. ON/OFF: power off/on switch

# Matrix Switcher control

Hunter Matrix switcher can support IR remote, APP, RS232/TCP/IP software, WEB GUI browser or the front push-buttons control.

## Remote control

Users also can control this matrix switcher with the remote control

# **Channel Switching**

Press the input from number "1~8", then press "SWITCH", then press the output from number "1~8", can press the outputs continually.

Eg. Switch input 1 to output 1, 2, 3: Switch 1,2,3

# • Scene Save

Press "SAVE", then press the scene number from "1~8". Eg, Save switching input 1 to output 1,2,3 to scene 2: "SAVE" "2"





#### • Scene Recall :

Press "RECALL", then press the scene number from "1~8". Eg, Recall scene 2: "RECALL" "2"

#### • EDID Setting:

Press "EDID" button to enter EDID setting mode, then press number "O" to choose the needed EDID, then press "ENTER" to confirm, or press number "9" to cancel or return to home page.

"EDID" "O" "ENTER"

#### • APP control

Users can download the APP from the Google play or Apple store by searching keywords "MCS", then need to make sure the Matrix switcher is connected to the WIFI router and the mobile devices is connected to the same WIFI. The default IP address of the matrix switcher is 192.168.1.80.

Open the APP and Enter the IP address of the matrix switcher:

Matrix Control System		
192.168.1.80	ENTER	

Click Enter and login with the user name and password, the default User name is admin, password is admin.

Matrix			Home	Caption	Config	Setup	Account
User Name Password	admin						
	Submit	Clear					



#### • WEB GUI browser Control

Users also can use the WEB browser to control the matrix switcher, users can have the matrix switcher connected with the PC with the LAN cable directly or have the matrix switcher connected the same network switch. The default IP address of the matrix switcher is 192.168.1.80.

After opening the browser, users can type the matrix switcher IP address and press enter: The default user name is admin and the password is admin.



After login, it will turn to "Home" interface, users can do the sources switching, scenes recall, save and the other devices control here.



Caption tab is from users to change then input, output, scene names, also can setup the control other devices commands here.

Matrix × +										~ -	<i>a</i> >
← → C ▲ Not secure   192.168.1.80/caption.shtml								ie 🛧	۰ 🕲 🔶	e 🖸 🛪	🗆 🎲 E
	Matrix				Home Caption C	Config Setup Account	Logout				
				Input							
	01 : Miplayer	02 : AppleTV	03 : Laptop	04 :	05 :	06 :					
	07 :	08 :									
	_			Output			-				
	01 : TV1	02 : TV2	03 :	04 :	05 :	06 :					
	07 :	08 :									
				Scene			- 10				
	01 :	02 :	03 :	04 :	05 :	06 :					
	07 :	08 :									
			Submit	Load							
				Control			-				
	01:			0 ~							
	02 :			0 ~							
	03 :			0 ~							
	04 :			0 ~							
	05 :			0 ~							
	06 :			0 ~							
	07 :			0 ~							
	08 :			0 ~							
			Submit	Load							

www.hunterindia.in



Config/EDID setting tab for users to select or setup the EDID for the specific inputs

Matrix		×	+															~	-	0	>	ĸ
← → C	A Not secur	19	92.168.1.80/Config.shtml											6 \$	) 1	<mark>ه ۱</mark>	•		<b>3</b> *		3	:
			<b>za ( vo nov</b> j somganni)	Mat 01 : 02 : 03 : 04 :	Inputing EDID sele 4K7.1 LCD TV 108012.1 108015.1 108015.1 1080P5.1 1080P5.1	rction	01 : [ 02 : [ 03 : [ 04 : [	Inputing audio selection HDIM Audio v HDIM Audio v HDIM Audio v HDIM Audio v	Home Capti a 01: 02: 03: 04:	Outputing Reso Outputing Reso bypass config bypass config bypass config bypass config	Account lution	Logout										
				05 : 06 : 07 : 08 :	100077.1 3D2.1 3D5.1 3D7.1 4K2.1 4K2.1 4K7.1 DVI-1024 DVI-1020 OUT1 OUT2 OUT1 OUT2 OUT3 OUT4		05 : 0 06 : 0 07 : 0 08 : 0	HDIM Audio v HDIM Audio v HDIM Audio v HDIM Audio v	05 : 06 : 07 : 08 :	bypass config bypass config bypass config bypass config	> > >	1.11										

Setup interface for users to do the IP address, COM baud rate and buzzer settings:

-																																			
M Matrix		×	+																													~	-	٥	×
$\  \   \leftarrow \  \   \rightarrow \  \   G$	A Not secur	e   19	92.168.1.	80/setu	p.shtml																						e 1	âr -	٠	6	•	ø	*	•	<b>)</b> :
								Matri	ix									Ho	ome C	Caption (	Config	Setup	Account	Logout											
							E					IPA	ddress	192	2.168.1	.80		]			_														
												Subnet	Mask	255	5.255.2	55.0		]																	
											Def	fault Ga	iteway	192	2.168.1	.1		]																	
												Ba	udrate	960	0			]																	
												H	Buzzer	M																					
												Lan	iguage	۲	Englis	h O Ch	ninese																		
													Submi	it	l	Load	R	Reboot																	
																								1.11											

Account interface for users to change the login user name and password:

M Matrix	× +							~	- (	a x
$\  \   \leftarrow \  \   \rightarrow \  \   G$	A Not secure   192.168.1.80/account.shtml				c	* E \$	00	-	* 🛛	🚱 E
		Matrix		Home Caption Config Setup Account Logout						
		User Name	admin							
		Password								
		Confirm Password								
			Submit Load							
				111						





### The 3rd Party Control command

# **IP address:** 192.168.1.80 (default IP) **Protocol:** TCP(5000), UDP(4000)

Second Sector Web And Second S		_		$\times$
UDP Setup Serial TCP Client TCP Server UDP Test Mode About				
Received/Sent data	TCD			
Connecting to 192.168.1.80			Deat	
Connected to 192.168.1.80	Module IP		Port	
1all.1all.2x2, 1x1, 3x3, 2x2, 1x1, 3x3,	192.168.1.8	30	5000	_
recalli, recalli, Recalli, Recalli, Recall2, Recall2, Recall9, Re		1		- 1
call9.	Ping		X Discor	nnect
	□ TEA authori	zation		
	TEA key			
	1.01020	304 3		IC
				_
	2: 05060	/08 4	UDDEOF	10
	Authorization	o code		
		redue		8
	PortStore te	est		
	□ NVT dis	able		
	Re	ceived b	est data	1
	Redirect I	o UDP		
Send				-
Tall.	Send			
2x2. 1x1. 3x3.	Send			
Recall9.	Send			

#### Section 2012 The section of the sect $\times$ UDP Setup Serial TCP Client TCP Server UDP Test Mode About Received data UDP -UDP socket created Module IP Port 192.168.1.80 4000 Local port X Close 4023 Server settings Server echo Sent data F Redirect to TCP Server reset. 1all. 2all. F Redirect to TCP Client UDP broadcast File name: No file Load file Send Send 1all. F HEX Send reset. T HEX Send 2all. ☐ HEX Send

#### www.hunterindia.in



#### RS232

Baud rate: 9600, N, 8, 1 Use RS232 direct cable

Commands	Functional Description	Example
Yall YxY YxY.YxY.YxY SaveY Recall[y] Reset	Switch input Y to all outputs Switch input Y to output Y Switch input Y to output Ys Save to scene Y Recall the save scene Y To reset account to admin/admin, IP address to default 192.168.1.80	Switch 1 to all outputs: 1all. Switch input 2 to output 9:2x9. Switch input 3 to output 2, 3, 4:3x2.3x3.3x4. Save to scene2: Save2. Recall to the scene 10: Recall10.

#### Package Content

- Hunter HDMI Matrix 8x8 (9304-HUV-M88A84K)
- Remote Control
- Rack Ear

