

# Hunter 4K HDMI Matrix 2x4 with audio

9174-HUC-M44A-4K

**USER MANUAL** 





# Product Introduction

Hunter HDMI matrix 2x4 can connect 2 HD signal sources to 4 HD display terminals with optical and stereo headphone output via HDMI out 1 port. The matrix allows two HDMI devices to be switched or split easily to four HDMI compatible monitors or projectors.

Hunter devices offer solutions for home, space and security concerns, data center control, information distribution, conference room presentation, school and corporate training environments.



#### Features



- Support 3D video format
- 2 HDMI inputs switch and split to 4 HDMI displays
- Support LPCM/Dolby/DTS 5.1 channel
- Via HDMI out1, support 3.5mm earphone jack and optical output at same time

176g


## **Specifications**



HDMI Resolution
Support Video Format
Support Audio Format
Max Bandwidth
Max Baud Rate
Input cable Distance
Output Cable Distance
Max Working Current
Operating Temperature Range
Operating Humidity range
Dimension
Weight

up to 3840\*2160/60Hz
8/10/12 bit deep color
LPCM/DTS/Dolby-AC3
600 MHz
3x6Gbps
4K/30Hz ≤15M AWG26 HDMI standard cable
4K/60Hz ≤5M HDMI 2.0 standard cable
750mA
(-15 to 45 C)
5 to 90%RH (No Condensation)
122x80x19 (mm)





- 1. Connect each HDMI source devices and input of Hunter HDMI Matrix with HDMI cable (For best results use Hunter HDMI Pro Cables).
- 2. Connect display devices and output of Hunter HDMI Matrix with HDMI cable.
- 3. Connect audio output and stereo amplifier with stereo headphone or optical.
- 4. Connect 5V power supply to the HDMI 2x4 Matrix.
- 5. Use the IR remote or button control to switch the signal source freely.

NOTE: HDMI port and audio ports are connected according to user needs, not every signal can be connected and can not be reversed.

## **Applications**



TV Store




Teaching Room



Video Conference







#### **Remote Control Unit**

1. HDMI Out1-4

2. R/L

3.DC/5V

4. Key1-4

5. IR

6. Optical 1-2

7. HDMI In1-2

8. Power

9. Out1/In1-2

10. Out2/In1-2

11. Out3/In1-2

12. Out4/In1-2

**HDMI** output

Stereo output;

5V power supply;

Video output1-4 switching button

IR Receive

Optical output

**HDMI** input

Power indicator

HDMI Out1 signal input indicator light

HDMI Out2 signal input indicator light

HDMI Out2 signal input indicator light

HDMI Out2 signal input indicator light

- The two buttons on Output1 is corresponding to input source In1-In2 which is out from Output1, In1-In2 can be switched freely.
- The two buttons on Output2 is corresponding to input source In1-In2 which out from Output2, In1-In2 can be switched freely.
- The two buttons on Output3 is corresponding to input source In1-In2 which out from Output3,In1-In2 can be switched freely.
- The two buttons on Output4 is corresponding to input source In1-In2 which out from Output4, In1-In2 can be switched freely.

#### Instruction of Buttons and LED:

- 1. Instruction of LED: In1-In2 indicator is the corresponding input sources out from Output1-Output4.
- 2. Operation of Buttons: Key1-Key4 is used to switched the corresponding input source out from Output1-Output4.



Pls use the Hunter HDMI Matrix as per instructions to increase the lifetime of the machine.

- 1. The machine should be placed at the spot far from the Damp, High-Temperature, Dusty, Erosive, and oxidative environment.
- 2. All parts will be free from the strong shake, hit, fall.
- 3. Touching the power adaptor with wet hands is prohibited.
- 4. Please hold the power adaptor head and do not pull the power cord when cut off from the socket.
- 5. Pls turn the power off when the machine is not used for long time.
- 6. Pls do not open the cover and do not touch the inside parts.
- 7. Pls use the original factory power adapter.

### Warranty 1 Year



If your product does not work properly because of a defect in materials or workmanship, our Company (warrantor) will, for the length of the period indicated as 1 Years, which starts with the date of original purchase ("Limited Warranty period"), at its option either (a) repair your product with new or refurbished parts, or (b) replace it with a new or a refurbished product. The decision to repair or replace will be made by the warrantor.

During the "Labor" Limited Warranty period there will be no charge for labor. During the "Parts" warranty period, there will be no charge for parts. You must mail-in your product during the warranty period. This Limited Warranty is extended only to the original purchaser and only covers product purchased as new. A purchase receipt or other proof of original purchase date is required for Limited Warranty service.